

## Installation Instructions

# Cushion Coupler



**PopUp**<sup>®</sup>  
Towing Products  
Mfg by Young's Products, LLC

4330 S. Johnson Road  
Chanute, KS 66720  
877-339-5704  
info@popuphitch.com

**WARNING: Verify adequate trailer swing clearance  
between trailer and cab of truck.**

### GOOSENECK EXTENDED CUSHION COUPLERS

**CC2**

4" Round

**CC4**

4" Round

**CC6**

4 1/2" Square

**CC8**

4" Square



1. Remove the stock coupler tube from the trailers receiver tube.
2. Fit the Cushion Coupler into the trailers receiver tube with the coupler release handle facing straight forward.
3. Secure your Cushion Coupler with the original set bolts and/or locking pin provided by the trailer manufacturer.

Note: The CC2 is provided with a safety collar which is used with trailers having one set bolt and a thru pin. The collar is not used with the offset cushion couplers.



Attach the cable to the coupler release lever with a cable clamp. Install eye bolts in the trailer neck to allow the cable to be run to a convenient location near the jack handle. When taking weight off the truck, simply pull the cable to release the coupler from the ball.

Lubricate the inside of the coupler with a thin film of lithium grease.

The three bolts thru the cushion are pre-set at the factory. No further adjustment is necessary.



Visit us on the web  
[www.popuphitch.com](http://www.popuphitch.com)

