

Installation Instructions

Cushion Coupler



PopUp[®]

Towing Products
Mfg by Young's Products, LLC

4330 S. Johnson Road
Chanute, KS 66720
877-339-5704
info@popuphitch.com

**WARNING: Verify adequate trailer swing clearance
between trailer and cab of truck.**

03/15

GOOSENECK EXTENDED CUSHION COUPLERS

CCK

4" Round
With King Pin

CC2

4" Round
With Coupler

CC4

4" Round
With Coupler
& 9" Offset

CC6

4 1/2" Square
With Coupler
& 9" Offset

CC8

4" Square
With Coupler
& 9" Offset

1. Remove the stock coupler tube from the trailers receiver tube.
2. Fit the Cushion Coupler into the trailers receiver tube with the coupler release handle facing straight forward.
3. Secure your Cushion Coupler with the original set bolts and/or locking pin provided by the trailer manufacturer.

Note: The CC2 is provided with a Lock Collar, which is used in place of a Thru Pin. The Collar is not used on the offset models.

4. Attach the cable to the coupler release lever with a cable clamp. Install eye bolts in the trailer neck to allow the cable to be run to a convenient location near the jack handle. When taking weight off the truck, simply pull the cable to release the coupler from the ball.

Lubricate the inside of the coupler with a thin film of lithium grease.

The three bolts thru the cushion are pre-set at the factory. No further adjustment is necessary



CC4



CCK



CC2



Visit us on the web www.popuphitch.com